

## **SYNC 2 /3 WIRELES PHONE MIRROR KIT**

Install the harness from the kit back of the APIM  
(behind the screen)

Whats our youtube videos

### **IPHONE**

<https://www.youtube.com/watch?v=TM4R8ve9NOo>

### **ANDROID**

<https://www.youtube.com/watch?v=DJYfj9objPs>

## **AUDO IN FACTORY SPEAKER SYSTEM FROM PHONE.**

Connect a usb thumb stick contaning a sigle mp3 file  
into the usb slot of the car.

### **OPERATION**

Press and hold VOL button for 7 sec untill screen  
switches to wireless phone mirroring

### **VIDEO IN MOTION**

Press "rear defrost" button X4 times with in a few  
seconds to enable/disable

**Note** works only on some cars